

Safety Warning

- All input and supply pressure to valve, actuator, and other related devices must be turned off when installing.
- YT-870 is designed for explosion proof area. The user must follow other explosion proof procedures and safety precautions.
- Make sure there is no explosive gas or material present before the installation.

YT-870 Installation

- O Assemble limit switch body with the bracket provided in the box.
- Align the main shaft of the limit switch box and the stem of the actuator. After the alignment, tighten the bracket onto the actuator.



