

Installation

Safety Warning

- All input and supply pressure to valve, actuator, and other related devices must be turned off when installing.
- YT-850 series is not proper for explosion area.
- For unused power connectors, please make sure to use blind plugs.

YT-850 Installation

- ① Assemble limit switch body with the bracket provided in the box.
- ② Align the main shaft of the limit switch box and the stem of the actuator.
After the alignment, tighten the bracket onto the actuator.

